




Model 801 EM Current Meter Operating Manual



Document Ref: 0801852a
Date: 08 August 2016

This document was prepared by the staff of Valeport Limited, the Company, and is the property of the Company, which also owns the copyright therein. All rights conferred by the law of the copyright and by virtue of international copyright conventions are reserved to the Company. This document must not be copied, reprinted or reproduced in any material form, either wholly or in part, and the contents of this document, and any method or technique available therefrom, must not be disclosed to any other person whatsoever without the prior written consent of the Company.

Valeport Limited
St Peters Quay
Totnes
Devon, TQ9 5EW
United Kingdom

Tel: +44 1803 869292
e mail: sales@valeport.co.uk
Web: www.valeport.co.uk

As part of our policy of continuous development, we reserve the right to alter, without prior notice, all specifications, designs, prices and conditions of supply for all our equipment.

Table of Contents

1. Introduction.....	3
2. Equipment.....	4
2.1. Standard 801 System.....	4
2.2. Wading Accessories.....	4
2.3. Options.....	4
3. Description.....	5
4. System Operation.....	8
4.1. Setting Up.....	8
4.2. Switch On.....	8
4.3. Running the Unit.....	9
4.4. Setting Units, Averaging Mode and Averaging Period.....	10
4.5. Option Menu.....	11
4.6. Logging Menu.....	12
4.7. Sub Options Menu.....	15
4.8. Analogue Output [Factory Fit Option].....	16
5. Power Supply.....	17
5.1. Changing Batteries.....	17
5.2. Battery Life.....	17
5.3. External Power [Factory Fit Option].....	18
6. Calibration.....	19
6.1. Adjusting Zero Offset.....	21
7. Care and Maintenance.....	23

1. Introduction

This manual covers the operation of the Valeport Model 801 Electromagnetic Flow Meter.

- Flat Type - 0801001
- Cylindrical Type - 0801002

2. Equipment

2.1. Standard 801 System

The standard 801 system has a choice of sensors and comprises the following. Both can be used with either 19 or 20mm diameter wading rods which customers may already have for use with impeller current meters:

0801013 Single axis, cylindrical sensor c/w 2m cable and connector

or

0801004 Single axis, flat sensor c/w 2m cable and connector

0801006 Wading Rod adaptor [only supplied for the flat sensor 0801004]

0801007 Allen Key for wading rod adaptor

0801005 Control and Display Unit

0801008 Carrying case

0801811 Operating manual

2.2. Wading Accessories

The following accessories are available for wading operations:

0801003 Set of 3 off 0.5 metre wading rods, graduated in centimetres, base and direction knob

0801010 Canvas shoulder bag for wading accessories

2.3. Options

0300012 Data cable to computer

0801011 Larger carrying case to take complete system with wading rods [instead of standard case and canvas shoulder bag]


0801017 Analogue output option

3. Description

The 801 electromagnetic flow meter uses the Faraday principle to measure the flow of water past the sensor. Two different types of sensor are available for the 801: the cylindrical sensor and flat sensor.

The cylindrical sensor has its electrodes on the side and the volume of water that is being sensed is a spherical volume around the sensor to a diameter of about 120mm. Because of this relatively large sensing volume, the cylindrical sensor should not be used in situations where the water boundary [bottom, sides or surface] is closer than 40mm to the sensor.

The flat sensor has the sensing electrodes on one surface of the sensor and these should normally be facing uppermost. The volume of water whose flow is being sensed is a cylinder between the electrodes and extending to approximately 10mm above the sensor. This sensor is therefore also suited to shallow applications. Because of the small sensing volume, if the water is turbulent, the real time readings of the flat sensor will fluctuate more than those of the cylindrical sensor.



The sensor should be aligned into the flow and the calibration is determined for +ve flow [flow on to the sensor at the electrode end] with the sensor upstream of the wading rod.

The sensor will detect negative flow and the same calibration is used, although there will normally be some interference caused by the turbulence from the wading rods. The unit is set to measure speeds up to 5 M/sec in both directions.

The system is calibrated as a combination of sensor with electronics in the Control Display Unit, and the serial number of both the probe and the CDU are displayed on the display on start up.

The system will operate in any conducting fluid, and the conductivity does not effect calibration. At very low conductivities the signal will, however, become noisier. A simple check is to check the noise in still water.

The CDU has its own internal batteries, and bulkhead connectors for the data interface to PC and the sensor. There is also a waterproof pressure equalising valve, to compensate for changes in temperature and atmospheric pressure that would otherwise cause the display membrane to distort. The connectors have waterproof pro-caps for when not in use. The CDU is designed for operation in rain conditions and for temporary immersion in water to 0.3m for 10 seconds, provided all connectors or pro-caps are fitted.

The EM system measures the flow twice every second, and calculates the real time flow every second as the average of the half second readings. The REAL TIME display is updated every second. The average speeds are computed as the average of the one second real time values over the averaging period which has been set [maximum period of 600 seconds]. If an average period is terminated early, then the calculation is based on the time since the average was started.

The 2Hz data from the EM system has been digitally filtered from raw 96Hz data. The filter is a Digital FIR filter with a fixed time delay and no frequency dependent phase shift. The filter -3dB cut off is 0.61Hz, and the delay time is 4.0 seconds.

The STANDARD DEVIATION [SD] is calculated from real time samples taken during the averaging period and gives an indication of the quality of the measurements. A high standard deviation indicates either a high variability in the flow, or the probe has not been held steady during the measurement.

There are 3 types of Averaging Modes:

Fixed average:

The unit performs one average over the period set. At the end of the averaging period the unit stops and displays the average and SD. It will commence another averaging period when requested by pressing START.

Free running:

This is fixed average with automatic restart of averaging period at the end of each period. The average and SD from the previous period are displayed and held during the subsequent period, until updated.

Moving average:

The average and SD are calculated over the averaging period set, and is updated every second. When STOP is selected, the display is frozen at the last average.

If the measurement period is terminated prematurely [by pressing the STOP key], the average values and standard deviation will be calculated over the time since the start of the current averaging period. The data [speed, SD, averaging period] is available for direct interfacing to a PC in real time [see Section 4.6.3. for interfacing information]:

- In fixed average a data string of average data is outputted at the end of averaging period.
- In moving average the last saved average is outputted when the user presses the STOP key.
- In free running mode the data is outputted at the end of each fixed average period and also when the user presses the STOP key.

The CDU can log up to 999 averages for subsequent display and/or transfer to a PC.

The optional analogue output is +/-5volts for the speed range +/-5 M/sec, and the analogue signal is based on the latest average figure shown on the CDU. The analogue output connector also enables external DC to be applied.

4. System Operation

4.1. Setting Up

To prepare the system for use:

- i. Clean the probe electrodes to remove any grease or dirt.
- ii. Insert batteries [8 off 1.5v C type cells], if external power not being used. It is recommended that alkaline type cells are used for maximum life.
- iii. Connect cables for particular combination of hardware being used.
- iv. If using with probe fixed to wading rods then assemble probe into adaptor [clamping using the small grub screw] and fix to rods, base and direction knob assembly.
- v. If mounting the probe by other means, it should be noted that the mounting may affect the flow characteristics and thus introduce an error into the measurement. Users can of course adjust results by carrying out their own calibration.

Once the system has been connected up, it is ready for use. For testing purposes, all of the CDU operations can be carried out without the sensor in water, but the real time data will be meaningless.

4.2. Switch On

ON

Switch unit On using ON button. This is acknowledged by a beep from the unit. This key is also used to switch the unit Off at any point during operation. Switching the unit On causes the following display to appear:

```

      8 0 1   S I N G L E   A X I S   E M   F L O W   M E T E R
      V A L E P O R T   M O D E L   8 0 1   V E R   2 . 0 0
      E M   S e r   N o   1 7 6 6 8   U N I T   S e r   N o   1 7 1 1 5
< < < O P T I O N S   S E T U P                               C O N T I N U E > > >

```

CONTINUE

Places the unit in Run Mode. See Section 4.3.

OPTIONS SET-UP

This key selects the OPTIONS menu, which allows the user to set up various hardware configurations [Logging On/Off, Beeper On/Off and Backlight On/Off]. This menu also allows access to the USER CALIBRATION menu, and to the LOGGING MENU. For further information refer to Section 4.5.

4.3. Running the Unit

Pressing **CONTINUE** at the title screen, or pressing **EXIT** at any of the **OPTION SET-UP** screens reveals one of the three possible displays shown below, depending on what mode the unit was in when last used [note that until **START** is pressed, no flow data is displayed].

DISPLAY 1: FIXED AVERAGE

```

      F I X E D   A V E R A G E   8 0 1   H H : M M : S S
T T T           S S S   S E C S
                                S T O P > > >
      R E A L   A V E R A G E
                                S E T U P > > >
+ X . X X X   + X . X X X   M / S E C   S D = X . X X X   S T A R T > > >
                                                L O W   B A T T
    
```

DISPLAY 2: MOVING AVERAGE

```

      M O V I N G   A V E R A G E   8 0 1   H H : M M : S S
S S S           S S S   S E C S
                                S T O P > > >
      R E A L   A V E R A G E
                                S E T U P > > >
+ X . X X X   + X . X X X   M / S E C   S D = X . X X X   S T A R T > > >
    
```

DISPLAY 3: FREE RUNNING

```

      F R E E   R U N N I N G   8 0 1   H H : M M : S S
T T T           S S S   S E C S
                                S T O P > > >
      R E A L   A V E R A G E
                                S E T U P > > >
+ X . X X X   + X . X X X   M / S E C   S D = X . X X X   S T A R T > > >
    
```

An explanation of the different averaging modes can be found in the Description, Section 3.

SETUP Press this key to alter current sampling regime. See Section 4.4.

START After an initialisation period of about 10 seconds, during which the following display will appear, the unit will begin sampling in the mode which has been set. The real time data will be displayed at the bottom of the screen, updated every second. In Free Running and Fixed Average modes, the count down within the average period is displayed. If the unit is in logging mode, the current record number will be displayed at the top right hand side of the screen. If the data interface lead is connected, the end of average values will also be sent to the PC.

```

INITIALISING EM
PLEASE WAIT

```

STOP Press to cease sampling. This will force an early end to an averaging period at the next second.

LOW BATT When there is approximately 4 hours of battery life remaining [with backlight], this message will be displayed at the bottom right hand corner of the screen [see DISPLAY 1 for an example]. The message will remain until batteries are replaced. See Section 5. for more information on power consumption and battery life.

4.4. Setting Units, Averaging Mode and Averaging Period

Selecting **SET-UP** in the Run Menu reveals the following display:

```

                RUN MENU SETUP
< < < M / SEC  FT / SEC                OPTIONS > > >
< < < FIXED  MOVING  FREE                ACCEPT > > >
< < < AVERAGE PERIOD    SSS    SECS

```

M/SEC FT/SEC Toggles between measuring the Speed in metres and feet per second.

FIXED MOVING FREE Toggles the averaging mode between the three states. Refer to Section 3 for further details.

AVERAGING PERIOD The Averaging Period which has been set is displayed. If it is required to change this, then press the key to move to the "Change Sampling" page. Refer to Section 4.4.1.

OPTIONS Press this key to return to the OPTIONS menu [Section 4.5.]

ACCEPT When the sampling regime is correctly set up, press this key to return to the RUN menu [Section 4.3.].

4.4.1. Changing Averaging Period

Selecting **AVERAGING PERIOD** in the RUN SET UP screen reveals the following display:

```

                                CHANGE SAMPLING
< < < 1 0 0 ' S
< < < 1 0 ' S                                INCR DECR > > >
                                S S S   S E C O N D S
< < < 1 ' S                                E X I T > > >
    
```

- INCR DECR** Toggles between increasing and decreasing the number of seconds when the relevant key is pressed.
- 100'S** Changes the number of 100's of seconds in the averaging period.
- 10'S** Changes the number of 10's of seconds in the averaging period.
- 1's** Changes the number of 1's of seconds in the averaging period.
- EXIT** Returns to the RUN MENU SETUP screen [Section 4.4].

Note that "000" seconds cannot be set, and the maximum is 600 seconds.

4.5. Option Menu

[Logging, Beeper, Backlight, Sub Options]

Pressing **OPTIONS SET-UP** at the Title Screen or **OPTIONS** in the Run Menu Setup screens reveals the following display.

```

                                OPTIONS MENU
< < < LOGGING YES / NO                                LOGGING MENU > > >
< < < BEEPER ON / OFF                                SUB OPTIONS > > >
< < < BACKLIGHT ON / OFF                                E X I T > > >
    
```

- LOGGING YES/NO** This key switches the logging facility On and Off. Up to 999 records may be stored.
- BEEPER ON/OFF** Toggles audible indication [once per second] that measurements are being made.
- BACKLIGHT ON/OFF** This key toggles it On and Off. Refer to POWER CONSUMPTION, Section 5 for details of battery life with and without backlight.
- LOGGING MENU** Allows access to LOGGING MENU. This enables the user to view or erase stored data, to extract it to a PC [via data interface lead], and

to set the unit date and time. Refer to Section 4.6.

SUB OPTIONS

This enables the user to go into the sub – options menu which allows direct EM communications with a PC [via data interface lead] for viewing EM data and setting of the calibration coefficients. Refer to Section 6. This sub-options menu also allows, if the options are fitted, frequency outputs and alarms to be set.

EXIT

Puts the unit into Run Mode, using the hardware configurations selected [see Section 4.3].

4.6. Logging Menu

Selecting **LOGGING MENU** at the **OPTIONS MENU** reveals the following display.

```

          LOGGING MENU
< < < SET  DATE / TIME          E X T R A C T  D A T A > > >
< < < R E S E T  # I D E N T          E R A S E  M E M O R Y > > >
< < < V I E W  D A T A                      E X I T > > >

```

SET DATE/TIME

Allows access to the **CHANGE DATE/TIME** screen. This allows the user to alter the unit's internal clock, for the purpose of correctly time stamping the recorded data. See Section 4.6.1.

RESET #IDENT

Sets the memory pointer to record #1 and updates the series letter. For example, a second series of records would begin with record #001B.

VIEW DATA

Allows user to see logged data. See Section 4.6.2.

EXTRACT DATA

Allows user to upload stored data to a PC. See Section 4.6.3.

ERASE MEMORY

Clears all stored data from the unit and resets data series identification to "A"; it does not reset **#IDENT** to zero which has to be done by the **RESET #IDENT** key, which should be done first otherwise the series B identification will be set. A screen will appear, requesting confirmation that the user wishes to erase memory. Press YES to continue, or EXIT to return to **LOGGING MENU**. If YES is pressed, a message will confirm that memory has been erased. Press **EXIT** to return to **LOGGING MENU**.

EXIT

Returns user to OPTIONS MENU. Refer to Section 4.5.


```

# I D E N T   F F F R

S P E E D   + X . X X X
S D =       X . X X X

A V   P E R I O D   S E C S   S S S

                                E X I T > > >

```

4.6.3. Extracting Data

Selecting **EXTRACT DATA** at the LOGGING MENU reveals the following display.

```

                                E X T R A C T   D A T A
                                                                U P L O A D > > >

                                P L E A S E   C O N N E C T   P C

                                                                E X I T > > >

```

Connect the unit to a PC via the data interface lead supplied. Run a terminal emulation program on the PC, ensuring that communications are correctly set to 4800 baud, 8 data bits, 1 stop bit, no parity bits, flow control NONE. If the data is to be saved on the PC, make sure that the data is directed to a file name. It is uploaded as a text file, with "Tab" delimiters, so it can be read into a word processor or spreadsheet application.

The data lead connector information is:

CDU end	Function	PC end
4 way in-line Male MilSpec connector [LMH06F 08 04 PN] [pins]		9 way "D" type female [sockets]
Pin A	RTS from PC [not used]	Socket 7
Pin B	Tx RS232 from PC to CDU	Socket 3
Pin C	Gnd	Socket 5
Pin D	Rx RS232C to PC	Socket 2

UPLOAD Begins to upload data to PC. Screens similar to those shown below will appear, and during uploading the #IDENT will increment.

EXIT Returns to LOGGING MENU. Refer to Section 4.6

```

                U P L O A D I N G   D A T A

                # I D E N T   F F F R
    
```

When data uploading is finished, the following screen appears, showing the **#IDENT** of the last record to be uploaded.

```

                F I N I S H E D   U P L O A D I N G   D A T A

                # I D E N T   F F F R

                E X I T > > >
    
```

EXIT Returns to LOGGING MENU. Refer to Section 4.6.

4.7. Sub Options Menu

Selecting **SUB OPTIONS** from the **OPTIONS MENU** reveals one of the following displays.

i. If Frequency or Alarm Outputs not fitted

```

                S U B   O P T I O N S   M E N U

                D I R E C T   E M   C O M M S > > >

                E X I T > > >
    
```

ii. If Frequency or Alarm Outputs fitted [Factory option]

```

                S U B   O P T I O N S   M E N U
< < < I N C R E A S E           1 0 0 H z   1 K H z   5 K H z   1 0 K H z > > >
< < < D E C R E A S E           D I R E C T   E M   C O M M S > > >
< < < H I A L A R M   + 1 . 2   L O   A L A R M   + 0 . 3   E X I T > > >
    
```

4.8. Analogue Output [Factory Fit Option]

The analogue output is factory set to provide +/- 5v for the range +/- 5 m/s. The voltage is derived from a D/A from the last updated average velocity figure. Alternatives analogue outputs are available including 4-20mA where the Control Display Unit provides the power for the 4-20mA. The wiring schedule for this is given in the second table.

The analogue output is made available from a data lead which has analogue out. A mating 6 way connector [LMH 06F 10 06 PN] is provided to enable users to terminate their own cable to this connector.

Connection details of the Y cable are:

CDU End	Function	Analogue Output
6 way female MilSpec bulkhead connector LMH 07A 10 06 SN [sockets]		6 way male Milspec connector LMH 06F 10 06 PN [pins]
Pin A	Signal Ground	Socket A
Pin B	Signal	Socket B

- These two are connected together in the mating connector. This "senses" that external DC is being applied.

Connection details of the 6 way bulkhead connector for a 4-20mA output are:

CDU End	Function	Analogue Output
6 way female MilSpec bulkhead connector LMH 07A 10 06 SN [sockets]		6 way male Milspec connector LMH 06F 10 06 PN [pins]
Pin A	GROUND - 4/20 Ma OUTPUT	Pin A
Pin B	CURRENT SINK (SIGNAL OUT) - 4/20 Ma OUTPUT	Pin B
Pin C	+20VDC SUPPLY - 4/20 Ma OUTPUT	Pin C
Pin D	RS 232 IN TO UNIT	Pin D
Pin E	RS 232 SIG GND	Pin E
Pin F	RS 232 OUT FROM UNIT	Pin F

5. Power Supply

5.1. Changing Batteries

The 8 "C" cells are housed in the battery compartment in the bottom of the CDU. Access is gained by unscrewing the central retaining screw and pulling out the end cap and pcb assembly. The cells can then be removed. When putting in new cells, be careful to ensure they are inserted the correct way. Labels are located in the compartment to indicate the correct way [note the large springs touch the -ve end on each cell, small springs the +ve end].

5.2. Battery Life

The current consumption of the units is as follows [all measured at 10vDC]:

	Backlight On	Backlight Off
Standby	92 mA	33 mA
Run	229 mA	171 mA

The battery life, based on good quality alkaline cells, operating at approximately 15 degC [note performance can reduce with low temperatures] and working on a duty cycle of 5 minutes On / 1 minute Standby is as follows:

	Elapsed Time (Hours)	Elapsed time Low Battery to Stop (Hours)	Actual On Time (Hours)	On Time LB to Stop (Hours)	% Duration to Low Battery
Backlight off					
Duration to low battery	34.00	3.50	28.33	2.91	91%
Duration to stop	37.50		31.25		
Backlight on					
Duration to low battery	20.50	7.00	17.08	5.82	75%
Duration to stop	27.50		22.92		

If the unit is left in standby, and if no button has been pressed for 5 minutes, the beeper emits 5 beeps to remind the user that the unit is still switched on. This feature does not operate when the CDU is connected to a PC for communications such as downloading data.

5.3. External Power [Factory Fit Option]

The unit will operate on an input voltage range of 7 to 15 vDC. The optional External DC power cable has 4mm plugs [Red +ve, Black -ve]. If these are connected using the wrong polarity, an internal fuse will blow. Refer to factory for instructions for repair.

The External DC power cable connection details are:

CDU end	Function	Free End
3 way in-line Male MilSpec connector [LMH06F 08 33 SN] [sockets]		4mm "banana" plugs
Pin A	+ve	Red
Pin B+C	-ve	Black

6. Calibration

Selecting **DIRECT EM COMMS** at the OPTIONS MENU enables the user, using a PC in terminal mode via the optional DC data lead to read and alter the EM calibration.

Connect the unit to a PC via the data interface lead supplied. Connection details are given in Section 4.6.3.

Run a terminal emulation program on the PC, ensuring that communications are correctly set to 4800 baud, 8 data bits, 1 stop bit, no parity bits, flow control NONE.

The EM calibration has 3 parts to it:

HYDRO CAL

This is the "shape" of the calibration curve and for normal routine calibrations the same calibration is used for all units of the same type.

SYSTEM GAIN FACTOR

The Gain Factor is specific to a combination of sensor and CDU, and is the factor by which all raw data from the electronics are multiplied to normalise the data to a standard counts per metre/sec.

SYSTEM ZERO OFFSET

The Zero Offset is specific to a combination of sensor and CDU, and the number of counts which the unit outputs at zero flow. See section 6.1 below for details on re-setting zero offset.

Having connected up the CDU and PC and entered DIRECT EM COMMS, the unit will output EM data at a rate of 2 Hz. Calibrated data from the EM electronics is in mm/sec. To communicate to the unit and interrupt it, press and hold the "#" key on the PC. When the unit responds with a §, enter a single # and press <cr>. The unit will respond with a "κ" [this may not be visible in all terminal programs if the font is not available] and then await a command. These commands are a series of "#" codes

Code	Followed By space and	Operation
#007	Output_Format<cr>	Sets the output format of the unit to CAL or NOCAL. CAL is data in calibrated units, NOCAL is raw counts and is used for calibrating purposes
#030	Nothing<cr>	Reads the output format CAL or NOCAL
#028	Nothing<cr>	Sets the unit into run mode. Data is outputted at the 2Hz rate.
#170	Zero_offset<cr>	Sets the zero offset in counts
#172	Nothing<cr>	Reads the zero offset which has been set
#174	Gain_Factor<cr>	Sets the GAIN_FACTOR
#176	Nothing<cr>	Reads the GAIN_FACTOR which has been set
#190	Nothing<cr>	Reads the Hydro Calibration which has been set
#192	Calibration<cr>	Sets the Hydro Calibration

If the user wishes to alter the calibration from the factory setting, it is necessary to enter the calibration coefficients. The calibration coefficients are stored within the micro-controller in an ASCII text string. The format of this string depends on the type of calibration (line fit or polynomial fit). The first part of the string will be the calibration function number, selected from the table

below, which defines the type of fit.

Calibration Function No.	OPERATION
0	Not defined
1	One straight line fit
2	Two straight line fit
3	Three straight line fit
4	Four straight line fit
5	Five straight line fit

The calibration takes the A/D counts, and calculates the engineering value from calibration coefficients. In all cases it is assumed that the -ve and +ve flow characteristics are the same.

Thus, for example, a three line fit calibration will be entered in the format shown below (note the single space between each value):

```
3 Coefficient1 Offset1 Max_It1 Coefficient2 Offset2 Max_It2 Coefficient3 Offset3
Max_limit3<cr>
```

The offset is the y axis [engineering value output] intercept at zero counts for the straight line segment

The coefficient is the slope of the straight line in engineering units per count.

The limit is the number of counts up to which the straight line is to be used [must be a positive number]

Where Max_It is the range up to but not including, which the straight line operates over.

The first straight line starts from 0 up to Max_It1 in A/D counts (WHOLE numbers).

The second straight line starts from Max_It1 and including it up to Max_It2 but not including it.

The third straight line starts from Max_It2 and including it , up to Max_It3 but not including it.

The last line limit [e.g. Max_It3 in the example above] must be set to more than the maximum number of counts, and Valeport usually use the figure 40000.

6.1. Adjusting Zero Offset

In the event that the zero offset requires adjusting from the factory set calibration, this can be done by the user using the following procedure.

6.1.1. Determining the Updated Offset

6.1.1.1. Method 1 - Using Data Displayed at Zero Flow

- Note the zero reading [Zr] in still water in mm/sec [note the display reading is in M/sec]. Great care should be taken to ensure that the water is still.
- From the calibration sheet, note the zero offset figure [in counts] defined for the unit [Zc1]. This figure can also be read from the unit by the #172<cr> command [see above].
- Calculate the new zero offset counts, Zc2 from the equation:

$$Zc2 = Zc1 - (Zr * (\text{Counts per mm/sec}))$$

The calibration is approximately 1mm/sec is 1 count, so the equation becomes:

$$Zc2 = Zc1 - (Zr * (\text{Counts per mm}\backslash\text{sec}))$$

For example:

Original zero offset in counts,	Zc1 = - 6.45
Zero reading in still water,	Zr = - 0.005 m/sec
	= - 5 mm/sec
New zero offset in counts,	Zc2 = - 6.45 - (-5)
	= - 6.45 + 5
	= - 1.45 counts

Note that it is important to use the correct signs

6.1.1.2. Method 2 – Reading Raw Real Time Counts

- Interrupt the unit using the **#<cr>** command detailed above
- Put the EM unit into NOCAL mode [i.e. to output data in raw counts], by entering **#007 "space" NOCAL <cr>**. Note that each time the unit is interrupted, it automatically goes back into CAL output mode, so the **#007 NOCAL<cr>** command has to be re-entered.
- The output mode can be checked by entering **#030<cr>** and the unit will respond with CAL or NOCAL as appropriate
- Make the unit go into RUN mode by entering **#028<cr>**
- The unit will output data at 2Hz, and with the sensor in still water, the counts for zero flow can be observed. Using the terminal emulation programme the data can be captured as a text file for averaging etc.

6.1.1.3. Setting the New Zero Offset

The new zero offset is entered by the command

#170 "space" zero offset<cr>

in the example above **#170 -1.45<cr>**

and is checked by **#172**

7. Care and Maintenance

While the instrument has been designed for field use, it is not indestructible and care should be taken not to damage either the sensor, cable or Control Display Unit.

In principle the calibration is for life, but as with most instruments it is advisable that check calibrations should be carried out on an annual basis.