


Connecting to a Station


1. Stop the station if it is logging.
2. Plug the smart sensor jack into an open smart sensor port on the station.
3. Start logging. See the station manual at www.onsetcomp.com/support/manuals for details on operating stations with smart sensors.

Mounting the Smart Sensor

- A solar radiation shield is strongly recommended when measuring air temperatures in direct sunlight. Solar radiation can be a significant source of error in the temperature and RH readings.
- Use the washer and screw (included with the M-RSA radiation shield) or cable clamps (included with the RS3-B radiation shield) to secure the smart sensor in the solar radiation shield. See the radiation shield manual at www.onsetcomp.com/support/manuals for additional details.



M-RSA mounting




RS3-B mounting

21837-B MAN-S-THB-QSG

Deployment Guidelines

- Thermally isolate the sensor from the mounting surface to ensure accurate air temperature and humidity readings. The probe's temperature sensor is at the end of the cable, just below the cap.
- Protect the probe from direct exposure to the weather to prolong sensor accuracy.
- Secure the smart sensor adapter to the mast with the cable ties as shown. Multiple smart sensor adapters can be stacked as shown in the far right example. Alternatively, mount the smart sensor adapter to a flat surface using two screws (no larger than a #6) and two washers.
- If the sensor cable is left on the ground, use conduit to protect against animals, lawn mowers, exposure to chemicals, etc.



One Smart Sensor Adapter Mounted

Two Smart Sensor Adapters Stacked and Mounted



For more information about this smart sensor, refer to the full product manual. Scan the code at left or go to www.onsetcomp.com/support/manuals/11427-man-s-thb.